



Application Programming Guide

OPOS Driver

Ver. 1.09

SPP-R200

SPP-R200II

SPP-R200III

SPP-R210

SPP-R300

SPP-R310

SPP-R400

BM10E

■ Table of Contents

| | |
|--|----------|
| 1. Instruction | 3 |
| 2. Development environment..... | 4 |
| 2-1 Communication Configuration..... | 4 |
| 3. Property / Method..... | 5 |
| 3-1 MSR Type..... | 5 |
| 3-2 Property Range / Default Value..... | 5 |
| 3-2-1 Capability property setting value..... | 5 |
| 3-2-2 MSR Method..... | 5 |
| 4. Error Information..... | 6 |
| 4-1 ResultCode List | 6 |

1. Instruction

This is a manual about how to set and configure device and to develop applications to use BIXOLON MSR with BIXOLON OPOS driver.

Before use BIXOLON MSR, set and configure MSR by using BIXOLON OPOS driver Setup Utility.

Throughout this manual, "OLE for Retail POS" is called "OPOS".

Throughout this manual, "Unified for Retail POS" is called "UPOS".

[Further Source]

OLE for Retail POS committee available from <http://monroecs.com/opos.htm>

Driver Update from <http://www.bixolon.com>

We at BIXOLON maintain ongoing efforts to enhance and upgrade the functions and quality of all our products. In following, product specifications and/or user manual content may be changed without prior notice..

2. Development environment

2-1 Communication Configuration

1) Communication Configuration for serial interface

You will set communication configuration in BIXOLON OPOS Setup Utility.

| Printer Model | Baud Rate | Product Type |
|---------------|-------------------------------|------------------------|
| SPP-R200 | 9600/19200/38400/57600/115200 | Optional built-in Type |
| SPP-R200II | 9600/19200/38400/57600/115200 | Optional built-in Type |
| SPP-R200III | 9600/19200/38400/57600/115200 | Optional built-in Type |
| SPP-R210 | Not Supported | Optional built-in Type |
| SPP-R300 | 9600/19200/38400/57600/115200 | Optional built-in Type |
| SPP-R310 | 9600/19200/38400/57600/115200 | Optional built-in Type |
| SPP-R400 | 9600/19200/38400/57600/115200 | Optional built-in Type |
| BM10E | Not Supported | Stand alone Type |

* Check the default communication setting. For more details refer to the user manual included in the printer package.

3. Property / Method

3-1 MSR Type

Property value will be determined by the MSR type, as shown in the below table.

3-2 Property Range / Default Value

3-2-1 Capability property setting value

| | | |
|---------------------------|---|-------|
| Capability Property | SPP-R200_MSR SPP-R200II_MSR SPP-R200III_MSR SPP-R210_MSR SPP-R300_MSR SPP-R310_MSR SPP-R400_MSR | BM10E |
| CapCompareFirmwareVersion | FALSE | FALSE |
| CapPowerReporting | TRUE | TRUE |
| CapStatisticsReporting | FALSE | FALSE |
| CapUpdateFirmware | FALSE | FALSE |
| CapUpdateStatistics | FALSE | FALSE |
| CapCardAuthentication | FALSE | FALSE |
| CapDataEncryption | FALSE | FALSE |
| CapDeviceAuthentication | FALSE | FALSE |
| CapISO | TRUE | TRUE |
| CapJISOne | FALSE | FALSE |
| CapJISTwo | FALSE | FALSE |
| CapTrackDataMasking | FALSE | FALSE |
| CapTransmitSentinels | TRUE | FALSE |
| CapWritableTracks | FALSE | FALSE |

3-2-2 MSR Method

| | |
|----------------------------------|---|
| Method | SPP-R200_MSR / SPP-R200II_MSR SPP-R200III_MSR / SPP-R210_MSR SPP-R300_MSR / SPP-R310_MSR SPP-R400_MSR BM10E |
| authenticateDevice | X |
| deauthenticateDevice | X |
| retrieveCardProperty | X |
| retrieveDeviceAuthenticationData | X |
| updateKey | X |
| writeTracks | X |

O: Supported X: Not supported

4. Error Information

This section is to explain returned error information when use MSR methods.
For more details, please refer to the UPOS specifications.

4-1 ResultCode List

ClaimDevice

| Method | Result Code | resultCodeExtended |
|-------------|----------------|--------------------|
| ClaimDevice | OPOS_E_ILLEGAL | 0 |

CheckHealth

| Method | Result Code | resultCodeExtended |
|-------------|-----------------|--------------------|
| CheckHealth | OPOS_SUCCESS | 0 |
| | OPOS_E_CLOSED | 0 |
| | OPOS_E_CLAIMED | 0 |
| | OPOS_E_DISABLED | 0 |
| | OPOS_E_ILLEGAL | 0 |
| | OPOS_E_OFFLINE | 0 |
| | OPOS_E_OFFLINE | 0 |

ClearOutput

| Method | Result Code | resultCodeExtended |
|-------------|-------------------|--------------------|
| ClearOutput | OPOS_SUCCESS | 0 |
| | OPOS_E_CLOSED | 0 |
| | OPOS_E_CLAIMED | 0 |
| | OPOS_E_NOTCLAIMED | 0 |